

## The Sentry Post and Belock Controller will stand watch over your dock.

Working together these two products will greatly enhance loading dock safety.

The BeLock Controller will not allow the door to be opened unless the restraint is engaged, or overridden by Management.

Once the BeLock is released the SentryPost takes over.

Two independent photo eyes detect movement around the dock leveler and inside the trailer. With an adjustable timer the warning light will remain flashing for a pre-determined amount of time, then turn off. The SentryPost will be active only when the dock door is unlocked and open.

After the door is closed and locked, the restraint becomes active and can then release the trailer.